PORODO



Porodo

MINIMA SLIM FOLDING KEYBOARD

SKU: PD2689BK

Preface

Thank you for choosing the Porodo MINIMA SLIM FOLDING KEYBOARD. This compact tri-fold keyboard combines bilingual typing, a numeric keypad, and a high-sensitivity touchpad for convenient control across compatible devices.



Package Contents

1. MINIMA SLIM FOLDING KEYBOARD × 1

Safety Precautions

Warning:

1. Keep the product away from water and excessive moisture.
2. Keep away from heat sources and open flames.
3. Do not disassemble, modify or repair the product yourself.
4. Charge through the USB-C interface using a certified power source rated at 5V/1A.
5. Do not use or charge the product if it is damaged, swollen, leaking or unusually hot.
6. Stop charging immediately if the product emits smoke, odor or unusual heat.
7. Keep fingers clear of the folding hinges to avoid pinching.
8. Keep the product out of reach of small children.
9. Do not puncture, crush, disassemble, or incinerate the product or its internal battery.
10. Do not use or charge the product with a damaged, frayed, loose, or defective USB cable, connector, or charging port; replace damaged charging accessories before use.
11. If the product emits smoke, odor, or unusual heat, stop using and charging it immediately, disconnect it from power if safe to do so, keep it away from combustible materials, and contact customer service for assessment.
12. Do not dispose of this electronic product or its internal battery with household waste; where applicable, use designated electronic-waste and battery collection facilities and follow local regulations, including the crossed-out wheeled-bin symbol requirements.
13. Do not use the keyboard while it is charging.

Attention:

1. Read this manual carefully before use and keep it for future reference.
2. Use the product only for its intended purpose.
3. Fold and unfold the keyboard gently without forcing the hinges.
4. Clean with a soft, dry cloth and do not use harsh chemicals.
5. Store the product in a cool, dry place when not in use.
6. Contact customer service if the product malfunctions.
7. Recharge the battery periodically during long-term storage to help maintain battery health.



Usage and Care Instructions

1. Charging the Keyboard

Inspect the USB-C cable, connectors, and charging port before use. Do not charge with damaged, frayed, loose, or defective charging accessories; replace them before charging.

Connect a compatible USB-C charging cable to the keyboard's charging interface.

Connect the other end to a 5V/1A USB power source.

Allow the battery to charge fully before extended use.

Disconnect the charging cable when charging is complete.

2. Unfolding and Positioning

Remove the MINIMA SLIM FOLDING KEYBOARD from storage and place it on a clean, stable surface.

Carefully unfold all three sections until the keyboard lies flat.

Make sure the hinges are fully opened and the keyboard is stable before typing.

Keep the folding joints clear of fingers and nearby objects when opening or closing the keyboard.

3. Bluetooth Pairing

Unfold and activate the MINIMA SLIM FOLDING KEYBOARD.

Enable Bluetooth on the device you want to use.

Activate the keyboard's pairing function using the key marked with the Bluetooth symbol.

Open the device's Bluetooth settings and select the keyboard from the list of available devices.

Wait for the connection to complete, then test the keyboard by typing in a text field.

4. Selecting the Operating System

Identify the operating-system selection keys printed on the keyboard.

Select the mode that matches the connected iOS, Android, or Windows device.

Wait briefly for the keyboard layout to update.

Test the main keys, shortcuts, and touchpad before beginning work.

5. Using the Touchpad and Numeric Keypad

Use the integrated touch surface to move the on-screen pointer.

Tap the touch surface to make a selection.

Use the printed numeric keypad layout for number entry and arithmetic functions.

Switch between touchpad and numeric input functions using the applicable printed control key.

Use light, controlled finger movements for accurate input.

6. Folding and Storage

Disconnect the keyboard from the device when it is no longer required.

Fold each section gently along its hinge without applying excessive force.

Make sure no objects are trapped between the sections.

Store the folded keyboard in a clean, dry location away from heavy objects.

Specifications

Input	5V/1A	Recharge Time	50min
Operating Frequency	2.4GHz - 2.480GHz	Folded Size	151.9 × 98.1 × 9.8mm
Battery Capacity	140mAh	Charging Interface	USB-C
Language	English, Arabic	Product Weight	160g
Working Time	56-60h	Bluetooth Version	5.0
OS Support	iOS, Android, Windows	Model Number	PD2689
Standby Time	100h	Operating Distance	10m
Unfolded Size	304.4 × 98.1 × 9.8mm		



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our Porodo website or shop come with a 24-month warranty.

When you buy Porodo products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at www.porodo.net/warranty and fill out the form with your information. Don't forget to upload a picture of the product too. After we have checked and accepted your request, we will send you an email to confirm that your product's warranty has been extended.

For more info, please check: www.porodo.net/warranty

Contact Us

Email: **info@porodo.net**

Website: **www.porodo.net**

Instagram: **porodo**