PORODO
LIFESTYLE



Porodo Lifestyle

LIGHTWEIGHT SLEEPING BAG

SKU: PDLFST170TBK

Table of Contents

Preface	2
Package Contents	2
Safety Precautions	2
Usage and Care Instructions	3
Specifications	5
Features	5
Maintenance Tips	5
Frequently Asked Questions	6
Troubleshooting	8
Disposal	9
Warranty	9
Contact Us	10

Preface

Thank you for choosing the Porodo Lightweight Sleeping Bag with Storage Pouch. Designed for comfort on the move, this lightweight polyester sleeping bag keeps you cosy on camping trips, hikes and overnight stays, and packs down neatly into its included pouch for easy transport and storage.



Package Contents

1. Lightweight Sleeping Bag x1
2. Storage Pouch x1

Safety Precautions

Warning:

1. Keep away from open flames, campfires, and other heat sources as the fabric is flammable.
2. Do not use near stoves, heaters, or smoking materials.
3. Keep the storage pouch and packaging away from children to avoid suffocation risk.
4. Do not use as a substitute for approved infant or child bedding.

5. Ensure adequate ventilation when sleeping inside to avoid restricted airflow.
6. Do not fully cover your head with the sleeping bag while sleeping.
7. Inspect for damage before each use and stop using if seams, zippers, or fabric are compromised.
8. Do not place on sharp, rough, or hot surfaces that could damage or ignite the fabric.

Attention:

1. Air out the sleeping bag before and after use to keep it fresh and dry.
2. Store loosely in a dry, well-ventilated place rather than compressed for long periods to preserve the filling loft.
3. Keep away from sharp objects, pets, and rodents that may tear the fabric.
4. Follow the care label instructions when washing; avoid harsh detergents and bleach.
5. Ensure the bag is completely dry before packing into the storage pouch to prevent mildew and odor.
6. Do not iron, dry clean, or expose to excessive heat during drying.



Usage and Care Instructions

1. Unpacking and Setup

Remove the sleeping bag from the storage pouch and unroll it on a clean, flat surface.

Allow the filling to loft up fully for a few minutes so the insulation reaches its intended thickness.

Fully unzip the bag if you would like to air it out before first use.

Lay the bag on a groundsheet, sleeping mat or tent floor for added insulation and comfort.

2. Everyday Use

Climb inside and close the side zipper to seal in warmth.

In warmer conditions, partially unzip the bag or use it as a quilt for ventilation.

Keep the bag away from open flames, sparks and hot surfaces such as stoves or lanterns.

Avoid dragging the bag on rough ground to protect the outer fabric from tears and abrasion.

3. Packing Away

Fully unzip the bag and shake out any debris.

Fold the bag lengthwise into a long strip roughly the width of the storage pouch.

Starting from the closed end, roll the bag tightly and evenly toward the zipper opening.

Slide the rolled bag into the storage pouch and secure the closure.

Specifications

Model Number	PDLFST170T
HS Code	9404309000
Fabric	170T polyester
Lining	170T polyester
Filling	200g/m^2
Weight	950g

Features

1. Lightweight construction ideal for camping, hiking and travel
2. Soft 170T polyester shell and lining for comfort against the skin
3. 200g/m^2 filling for warmth on cool nights
4. Full-length side zipper for easy entry, exit and ventilation
5. Quilted baffle design helps distribute the insulation evenly
6. Includes a compact storage pouch for easy carrying and storage

Maintenance Tips

1. Keeping Your Sleeping Bag in Great Condition

Air the sleeping bag out after each use to release moisture and odours before storing.

Spot clean small stains with a damp cloth and mild soap rather than washing the whole bag when possible.

When washing is required, follow the care label: gentle wash at 30 °C, no bleach, no tumble dry, no ironing and no dry cleaning.

Ensure the bag is completely dry inside and out before packing it away to prevent mildew.

Store loosely folded or hung in a cool, dry place for long periods; prolonged tight compression can reduce loft and warmth.

Keep the bag away from sharp objects, open flames and heat sources to protect the fabric and filling.

Close the zipper carefully and avoid forcing it over trapped fabric to keep it running smoothly.

Frequently Asked Questions

1. Is this sleeping bag suitable for cold winter camping?

This is a lightweight sleeping bag with 200g/m^2 polyester filling, best suited to mild to cool conditions. For deep winter or sub-zero nights we recommend a heavier, higher-fill sleeping bag.

2. Can two bags be joined together?

This model is designed as a single sleeping bag and is not intended to be zipped to another bag.

3. Is the sleeping bag machine washable?

The care label indicates gentle machine washing at 30 °C. Do not bleach, do not tumble dry, do not iron and do not dry clean. Always follow the symbols printed on the sewn-in care label.

4. How should I store the sleeping bag between trips?

For short trips the storage pouch is convenient, but for long-term storage keep the bag loosely folded or hung in a dry, well-ventilated place so the filling stays lofted.

5. What are the sleeping bag's dimensions and weight?

The bag weighs approximately 950g. Refer to the Specifications section for full material and weight details.

6. Can it be used indoors, for sleepovers or guests?

Yes. The bag works well as a comfortable indoor bedding option for guests, sleepovers or travel stays.

Troubleshooting

Problem	Likely Cause	Solution
Sleeping bag feels less warm than expected	Filling has not fully lofted after unpacking	Unroll the bag and shake it out; allow 10–20 minutes for the insulation to fully expand before use.
Cold spots along the body	Cold ground drawing away heat	Use a sleeping mat or groundsheet underneath to insulate the bag from the floor.
Zipper is stuck	Fabric caught in the zipper teeth	Do not force the zipper. Gently pull the trapped fabric free while easing the slider back, then re-zip slowly.
Zipper separates behind the slider	Zipper is worn or misaligned	Fully unzip and re-engage the slider carefully from the base; avoid overloading the zipper.
Damp or musty smell	Bag stored while still damp	Air out fully in a dry, ventilated space, or wash gently per the care label and dry thoroughly before storing.
Bag feels flat or thin over time	Long-term compression in the storage pouch	Store loosely folded or hung between trips to preserve the loft of the filling.
Stains or dirt on the shell	General outdoor use	Spot clean with a damp cloth and mild soap; only machine wash when necessary using the care label instructions.

Problem	Likely Cause	Solution
Small tear in the outer fabric	Snag from a sharp object or rough ground	Repair promptly with a fabric patch or repair tape to prevent the tear from spreading and filling from escaping.
Filling shifts to one end of the bag	Uneven distribution after washing	Lay the bag flat and gently redistribute the filling by hand; shake and pat until the baffles feel even.
Storage pouch feels too small when packing	Bag folded rather than rolled	Fold the bag lengthwise, then roll tightly from the closed end toward the zipper opening before inserting.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our Porodo website or shop come with a 24-month warranty.

When you buy Porodo products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at www.porodo.net/warranty and fill out the form with your information. Don't forget to upload a picture of the product too. After we have checked and accepted your request, we will send you an email to confirm that your product's warranty has been extended.

For more info, please check: www.porodo.net/warranty

Contact Us

Email: **info@porodo.net**

Website: **www.porodo.net**

Instagram: **porodo**